


# SHIMANO

## STELLA S A-RB

## STL-3000HG



**Do not disassemble the reel**

This reel is a precisely manufactured product. Disassembling the reel may result in decreased performance. Problems caused by unauthorized disassembly are not covered by warranty.

Please note that the number of adjusting washers may not be the same as shown in the exploded views.

(51SE41F032X)

(Adjustment will vary with each individual product.)

Part No.	Description	Part No.	Description	Part No.	Description
RD 1524	Washer	RD14376	Handle Knob I.D. Plate	RD16599	Rotor
RD 2110	Screw	RD14778	Drag Click	RD16600	Bail Hold Support Guard
RD 3538	Spool Support	RD14780	Screw	RD16601	Bail Assembly
RD 3561	Screw	RD14866	Ball Bearing	RD16602	Rotor Guard
RD 3571	Screw	RD15488	Key Washer	RD16603	Ball Bearing
RD 6008	Set Screw	RD15489	Drag Click Spring	RD16605	O Ring
RD 6109	Spool Washer	RD15718	Screw	RD16606	Pinion Gear Spacer
RD 7788	Spring Guide (A) Support	RD15991	Rotor Nut Lock Plate	RD16607	Ball Bearing
RD 8074	Bearing Water Proof	RD15992	Rotor Nut	RD16608	Idle Gear B Shaft
RD 8174	Screw	RD16422	Drag Knob	RD16609	Body Flange Seal
RD 8388	Drag Washers Retainer	RD16423	Drag Washer	RD16610	Idle Gear
RD 8916	Click Spring	RD16426	Screw	RD16611	Friction Ring Spacer
RD 9833	Ratchet Spring	RD16431	Line Roller	RD16613	Side Cover
RD 9841	Click Pin	RD16440	Line Roller Support	RD16616	Oscillating Pawl Cover
RD 9847	Screw	RD16444	Screw	RD16617	Oscillating Slider Bushing
RD 9849	Screw	RD16446	Roller Clutch Water Proof	RD16618	Oscillating Pawl
RD 9903	O Ring	RD16448	O Ring	RD16619	Main Shaft Assembly
RD 9908	Drag Washer	RD16449	Roller Clutch Inner	RD16620	Rear Protector
RD 9912	Bearing Retainer	RD16450	Roller Clutch Inner Spacer	RD16621	Rear Shield
RD10040	Screw	RD16451	Screw	RD16622	Worm Shaft Retainer
RD11018	Ball Bearing	RD16452	Bearing Retainer	RD16623	Oscillating Guide B
RD11568	Screw	RD16462	Flange Water Proof	RD16624	Idle Gear B S
RD11578	Ball Bearing	RD16465	Handle Shaft Seal	RD16626	Screw
RD11591	Eared Washer	RD16466	Handle Shaft Cover B	RD16627	Worm Shaft
RD11607	Friction Ring	RD16472	Washer	RD16628	Oscillating Guide
RD11610	Bail Trip Strike	RD16477	Rear Protector Collar	RD16635	Spool Assembly
RD11646	Drag Click Ratchet	RD16480	O Ring	RD16636	Pinion Gear
RD12360	Washer	RD16492	Handle Shaft Cover	RD16637	Drive Gear
RD13241	Ball Bearing	RD16493	Handle Shank Assembly	RD16638	Handle Assembly
RD13269	Ball Bearing	RD16496	Handle Screw Cap	RD16639	Idle Gear B L
RD13274	Ball Bearing	RD16587	Key Washer	RD16640	Body
RD13381	Ball Bearing	RD16590	Rotor Brim	RD16668	Roller Clutch Assembly
RD14252	Screw	RD16591	Line Roller Plate	RD16838	Main Shaft Spacer
RD14258	Bail Trip Cam Bushing	RD16592	Bail Spring Guide A	RD16946	Rotor Ring
RD14259	Washer	RD16593	Bail Spring	RD16947	Bearing Spacer
RD14260	Screw	RD16594	Bail Spring Seat	RD16948	Roller Clutch Reinforce
RD14277	Large Handle Shank Washer	RD16595	Bail Trip Lever		
RD14279	Washer	RD16596	Bail Arm		
RD14300	Bearing Bushing	RD16597	Screw		
RD14375	Handle Knob	RD16598	Bail Spring Cover	RD 9811	Reel Seat Spacer (accessory)